

[1] Change direction:
Step1: Setup direction
Step2: Set PWM or RPM to 0
Step3: Set PWM or RPM to a value more than 0