

序号	Wakeup word	UART0 output	Speaker Play	Note
1	Hi, M five	AA 55 FF 55 AA	I'm here	
序号	Command word		Speaker Play	Note
1. 方向控制（Direction Control）				
1	up	AA 55 01 55 AA	OK	
2	down	AA 55 02 55 AA	OK	
3	left	AA 55 03 55 AA	OK	
4	turn left	AA 55 04 55 AA	OK	
5	right	AA 55 05 55 AA	OK	
6	turn right	AA 55 06 55 AA	OK	
7	forward	AA 55 07 55 AA	OK	
8	front	AA 55 08 55 AA	OK	
9	backward	AA 55 09 55 AA	OK	
10	back	AA 55 0A 55 AA	OK	
2. 操作命令（Operation Commands）				
11	open	AA 55 10 55 AA	OK	
12	close	AA 55 11 55 AA	OK	
13	start	AA 55 12 55 AA	OK	
14	stop	AA 55 13 55 AA	OK	
15	turn on	AA 55 14 55 AA	OK	
16	turn off	AA 55 15 55 AA	OK	
17	play	AA 55 16 55 AA	OK	
18	pause	AA 55 17 55 AA	OK	
19	turn on the lights	AA 55 18 55 AA	OK	
20	turn off the lights	AA 55 19 55 AA	OK	
21	previous	AA 55 1A 55 AA	OK	
22	next	AA 55 1B 55 AA	OK	
3. 数字（Numbers）				
23	zero	AA 55 20 55 AA	OK	
24	one	AA 55 21 55 AA	OK	
25	two	AA 55 22 55 AA	OK	
26	three	AA 55 23 55 AA	OK	
27	four	AA 55 24 55 AA	OK	
28	five	AA 55 25 55 AA	OK	
29	six	AA 55 26 55 AA	OK	
30	seven	AA 55 27 55 AA	OK	
31	eight	AA 55 28 55 AA	OK	
32	nine	AA 55 29 55 AA	OK	
4. 确认与问候（Acknowledgment & Greetings）				
33	ok	AA 55 30 55 AA	OK	
34	hi, A S R	AA 55 31 55 AA	I'm here	wakeup directly
35	hello	AA 55 32 55 AA	I'm here	wakeup directly
5. 系统控制				
36	increase volume	AA 55 40 55 AA	OK	
37	decrease volume	AA 55 41 55 AA	OK	
38	maximum volume	AA 55 42 55 AA	OK	
39	medium volume	AA 55 43 55 AA	OK	
40	minimum volume	AA 55 44 55 AA	OK	
41	check firmware version	AA 55 45 55 AA	Version One	
6. 产测用指令		串口回复指令		
42	AA 55 FE 55 AA	AA 55 FE 55 AA	Hi, I'am ASR	